PLANTED-IN-PLACE GREEN ROOF DETAILS

TR1.01 GREEN ROOF TRAY

- TR1.02 TRAY LAYOUT
- TR1.03 TRAY CONNECTION
- TR1.04 TRAY CONNECTION AT CRICKET
- TR1.05 PLANTING METHOD- SEDUM TILE OR MAT
- TR1.06 PLANTING METHOD- SEDUM PLUGS
- TR1.07 PLANTING METHOD- SEDUM CUTTINGS
- TR2.01 VEGETATION FREE ZONE- PEDESTAL PAVER
- TR2.02 VEGETATION FREE ZONE- BALLAST ROCK
- TR2.03 VEGETATION FREE ZONE- PAVER OVER ROCK
- TR2.04 VEGETATION FREE ZONE- ROOF PENETRATION
- TR2.05 WALKWAY- BALLAST ROCK
- TR2.06 WALKWAY- PAVER OVER BALLAST ROCK
- TR2.07 WALKWAY- PEDESTAL PAVER
- TR3.01 TRAY EDGER, STANDARD
- TR3.02 TRAY EDGER, IRRIGATION HEADER
- TR3.03 TRAY CONNECTION AT WALL
- TR3.04 FLASHING AT PARAPET

- TR4.01 DRIP IRRIGATION LAYOUT
- TR4.02 IRRIGATION CONTROLS- SCHEMATIC
- TR4.03 DRIP TUBING CONNECTION TO TRAY

ISSUE DATE: 06/18/2014

TR4.04 IRRIGATION VALVE BOX




PLANTED-IN-PLACE GREEN ROOF TRAYS





PLANTED-IN-PLACE TRAY


DETAIL SCALE: VARIES


Corporate Office: 79 SE Taylor Street, Suite 201 Portland, OR 97214














Corporate Office: 79 SE Taylor Street Suite 2


Corporate Office: 79 SE Taylor Street, Suite 201 Portland, OR 97214 Telephone: (503) 327-8723 · www.columbia-green.com








Corporate Office: 79 SE Taylor Street, Suite 201 Portland, OR 97214 Telephone: (503) 327-8723 · www.columbia-green.com


































Corporate Office: 79 SE Taylor Street, Suite 201 Portland, OR 9721 Telephone: (503) 327-8723 www.columbia-green.com

